



Fitting Instructions



Proudly Australian Made

Yamaha R6 1998-2002



1. Remove the fairing from both sides of the bike.
2. Also remove the horn if you find that it is getting in the way.
3. Remove the bottom bolt that mounts the radiator to the bike.
4. Slip and clip the RAD GUARD in front of the radiator and behind the horn.
5. Line up the bottom of the RAD GUARD with the same mounting point that the bottom bolt originally came from and then bolt it back into place.
6. Replace the horn if you have taken it off.
7. Now replace all of the fairing.